Likebook Mimas 8.1 Upgrade

Reference Video (upgrade button is different):

https://mega.nz/file/mVxAQJgZ#Pb6BZGCOvtGe m69Z35L8masCM1JxjdOf1IVN9OFIupA

First, warm reminder:

- 1. Please properly back up all important files in advance, upgrade will clear all the file contents.
- 2. Make sure device memory and power are sufficient (power-more than 50%).

3. Turn off the device!


- 4. PC: Windows 7/10; English system (Better).
- 5. All files downloaded please copy to C driver of your PC

Upgrade steps:

1. Driver installation:

https://mega.nz/file/TFYUBQpZ#j562jVKd2w2a9ZXItVav0A7H rNRmWUVfg28zGkGgGJk

Open the driver folder, double-click "DriverInstall.exe", and click Driver Installation.



2. Confirm installation




3. Open the flashing tool folder and double-click "AndroidTool.exe"

(P.S. Put the android tool in the root directory of your PC)

https://mega.nz/file/DRhQGSwT#mCcvipndWB8k4Qbyl7BVtviK77siYBGEV8

C158tLXJ4




4. Select software:

Click the "Firmware" button and select the software which you need to flash.

Software: (ONLY FOR MIMAS, BUT NO OTHER MODEL!!!)

https://mega.nz/file/SNBWGJwK#JtJEGRXBUiCCHeYOBtsa-vA8dRIIOZnGeULb5P D4ks




5. Connect the equipment for rooting:

Power off the device! Press and keep holding the "upgrade key" (as picture shown) before inserting the USB cable. Then Insert USB cable for connection at the same time.



6. After the flash tool reads the device, it will display the "Loader" device.

You can only loose the "upgrade key" holding now. Then click "Upgrade" to root the device.



7. When the rooting finished, there will be "Reset Device Success" reminder on the right side of tool. (Please wait the device to restart and keep USB cable connection during this time)

