

<i>Modell</i>	Display	Touch	glossy	matt	Akku	Tasten	Mp3	USB-Host	WLAN	Bluetooth	UMTS
360°	5"	no	no	yes	1000mAh	Joystick/2 Wingbuttons	no	no	no	no	no
301	6"	no	no	yes	1000mAh	Joystick/2 Wingbuttons	yes	no	no	no	no
302	6"	yes	yes (but Antireflex)	no	2000mAh	BackButtonf/4 Wingbuttons	yes	yes	yes	yes	no
501	5"	no	no	yes	1000mAh	Joystick/2 Wingbuttons	no	no	yes	yes	no
502	5"	no	no	yes	1000mAh	Joystick/2 Wingbuttons	yes	no	yes	yes	no
503	5"	yes	no	yes	2000mAh	Joystick/2 Wingbuttons	yes	yes	yes	yes	yes
601	6"	no	no	yes	1000mAh	Joystick	yes	no	no	no	no
602	6"	yes	no	yes	1000mAh	Joystick/2 Wingbuttons	yes	yes	yes	yes	no
603	6"	yes(Wacom)	no	yes	2000mAh(?)	Joystick	yes	yes	yes	yes	yes
901	9,7"	no	no	yes	2000mAh	Joystick/Wing+Functionbuttons	no	no	no	no	no
902	9,7"	no	no	yes	2000mAh	?	?	?	yes	yes	no
903	9,7"	yes	no	yes	2000mAh	?	yes	yes	yes	yes	yes