

You're currently on: [Support Center](#) » [Questions & Answers](#) » [Migrating content to SD card or microSD card](#)

## Support Center

 Migrating content to SD card or microSD card

### Article

NOTE: Once you move your content to an SD card or microSD card, you will not be able to revert to internal storage.

To migrate (move) your content to an SD card or microSD card:

Select Settings.

Select Device storage.

Select Data storage device.

Select SD card. Make sure you have an SD card with sufficient space. A dialog will open explaining the requirements for migration. Confirm to continue.

### Article Details

Article ID:

259

Created On:

16 Dec 2010 3:22 PM

 [This article was helpful](#)

 [This article was not helpful](#)



### Search Questions & Answers

  
-- Entire Support Site --

### Article Options

-  [Print Article](#)
-  [E-mail Article](#)
-  [Add to Favorites](#)

[« Back](#)